Maintenance

- It is recommended to wait for 2 minutes to reuse your Electronic Cigarette after you have replaced the used-up cartomizer with a new one.
- Be sure to keep your battery threads, and cartomizer threads cleans with dry tissue. Cleaning your threads will provide a good connection ensuring a proper charge and good vapor production. If your connections are not clean, the battery might not charge or vapor production might be low.

Precautions

- The proper operation procedures must be followed to prevent malfunction and damage to the product. We do not accept warranty claims if you use other operation procedures other than the ones stipulated herewith.
- Keep you Electronic Cigarette separate from other articles such as keys and change, which could collide with the device and cause cosmetic or functional damage to your Electronic Cigarette. Warranty claims for cosmetics will not be accepted.
- In the case that a problem should arise with your Electronic Cigarette, please contact us and do not try to dismantle it by yourself. Opening the Electronic Cigarette battery compartments or button compartment will result in complete malfunction of your Electronic Cigarette and voids the warranty.
- Keep from "HIGH" temperature extremes and humidity.
- Keep your Electronic Cigarette out of children's reach, and avoid improper operation.

Please Note

- Persons under 18 years of age are not permitted to purchase or use the **Regal** electronic cigarette. Non-smokers, children, pregnant women, women who may become pregnant, women breastfeeding or persons with or at risk of heart disease, high blood pressure, diabetes, or taking medicine for depression or asthma should not use this product.
- The **Regal** electronic cigarette is intended for current smokers over the age of 18 who wish to use **Regal** Cigs as an alternative to traditional cigarettes without the tar and carcinogens.
- You should consult your physician before using the **Regal** electronic cigarette because it may or may not contain nicotine.
- If you are smoking tobacco products you are encouraged to stop.
- Please keep out of reach of children. Some parts of the **Regal** Cig may be a choking hazard.

Can I use Regal to Stop Smoking?

The **Regal** electronic cigarette has not been tested as a stop smoking device and has not been advertised as a quit smoking device. If you wish to quit smoking, please consult your doctor or pharmacist.

Regal Limited Warranty

We stand behind the quality of our product and guarantee to the original purchaser that our product shall be free from defects in material or workmanship for a period of one year from the original purchase date. This warranty applies to the product under normal use and is subject to all product usage documentation. In the event you need to exchange your **Regal** battery, or charger, simply call customer service at **1-888-822-5977** to obtain a Return Merchandise Authorization (RMA). Place the RMA number and the item(s) to be exchanged in a padded envelope, and mail it to us at **Regal** Cigs Returns, 405 W. Fairmont Drive, Tempe, AZ 85282

The warranty will not apply if the product is used with non **Regal** certified or approved products, used for commercial purposes, damaged by wear and tear, acts of God, misuse, abuse, negligence, accident, modified or tampered with or any other cause other than defective material or workmanship.

Classic Tobacco Flavor Regal Cartomizer

For those that enjoy the taste and feel of a rich full tobacco flavored cigarette, Classic has you covered. Try Classic and immerse yourself in tobacco country without the smell or aftertaste.

Customer Care

If you have any questions or comments please email customer service at **support@Regalcigs.com** or call our customer care line at **1-888-822-5977** or visit our website www.**Regal**cigs.com

Order your refill cartridges at:
Regalcigs.com

Rev 01/13

Premium Starter Kit User Manual

regal ecigs

www.**Regal**cigs.com

What is the Regal Electronic Cigarette?

The **Regal** electronic cigarette is an alternative smoking device that consists of the cartomizer and battery containing an LED light that lights up each time you inhale

An Electronic Cigarette, also known as the smokeless electronic cigarette or a personal vaporizer, can be used as an alternative to tobacco cigarettes, cigars, or pipes by providing the physical sensation of smoking or “vaporizing”. It is comprised of 1 a cartomizer and 2 a rechargeable lithium ion battery.



The sealing for the cartomizer is a Silica Gel Stopper which needs to be removed. Each cartomizer has a small silicone freshness plug which must also be removed before using.

Assembly

Directly screw the cartomizer onto the corresponding part on the battery until it fits firmly into place. Do not use force when doing this and do not over tighten the cartomizer.

The Electronic Cigarette provides vaporized E-liquid and does not actually “burn” anything, which is the major cause of the 4000 carcinogens that are found in a burning tobacco cigarette. It is powered by a rechargeable battery, along with which there is an intelligent microchip providing a cut-off function and overcharge protection. The expected duration for one charge is individual and depends on how frequently you use it.

Charging

To charge your Electronic Cigarette, gently unscrew the Cartomizer by turning it counter clock-wise until you are able to remove it. Once removed, gently screw the battery onto the charger’s corresponding threads. The battery LED will stay red during the charging period and the battery LED will go off when the battery is fully charged. (Please note: charging can take up to two hours.) DO NOT OVER TIGHTEN BATTERY INTO CHARGER as it can ruin the charging unit. Charging must be within normal room temperatures.

FLASH NOTICE

When the battery light flashes:

- **2 times:** if you are smoking continuously for 5 seconds, the battery will blink 2 times to remind you to take a rest.
- **2 seconds:** it indicates that there is a short circuit inside the cartomizer.
- **10 times:** it indicates that the battery is in need of recharging.

Regal cartomizers are designed to only be used with your **Regal** electronic cigarette and should not be used with any other device or for any other application. Once a cartomizer is empty it will not produce vapor and can be replaced.

Regal Cartomizer Longevity

Your **Regal** cartomizers should last for 500 puffs on average. This means 1 **Regal** cartomizer is equivalent to 50 traditional cigarettes. Results will vary depending on the habits of the individual user.

Regal Battery Longevity

Your **Regal** batteries are the very latest technology, and while small, should last you 2 cartomizers between charges. Once depleted, the batteries take 1-2 hours to fully recharge.

How to properly use your Regal

Once you have charged your batteries and placed your first cartomizer on the **Regal** electronic cigarette you are ready to start using it. Simply place the cartomizer end in your mouth and inhale like a normal cigarette.

This will initiate the cartomizer, which will vaporize the liquid and allow you to inhale an exhale vapor. The level of vapor (smoke) you exhale is dependant on how hard you inhale on the cigarette. Each time you ‘drag’ on your **Regal** electronic cigarette the LED light on the tip will light to indicate it is working properly. This is the only way your **Regal** electronic cigarette is designed to be used and should not be used in any other manner.

Nicotine Consumption

Regal cartomizers come in various flavors levels of nicotine: None, Light, Medium, and Full Flavored. The **Classic Tobacco** flavored cartomizers contain between 0-16 mg of nicotine. Nicotine is an addictive drug. When using cartomizers that contain nicotine, you will inhale vapor that contains nicotine and it will be absorbed into you body. To avoid over consumption the **Regal** electronic cigarette will automatically warn you by flashing 2 times to signify you have puffed continuously for 5 seconds. This will not affect the operation of your **Regal** electronic cigarette but it is recommended that you put the **Regal** electronic cigarette down and stop using for a small period of time to prevent overconsumption. If at any time you feel dizzy or nauseous please stop using he device immediately and consult your doctor.